


| You are in: [Lozier Products](#) > [Products](#) > [S-Series Storage Crossbrace](#)

S-Series Storage Crossbrace

Part Number: **Part Number: SSX**



Product Details:

- S-Series Storage Sections must be stabilized with either Crossbraces or Back Panels
- Crossbraces (or Back Panels) are required on end sections of each run and every fourth section in between for stabilization
- See diagram below for minimum recommended placement of Crossbraces per run
- Back-to-back runs can share Crossbraces if Uprites are securely connected with S-Series Storage Screws (#SS2221)
- If section height is over 96", the part number below includes two sets of Crossbraces for the section (one lower and one upper Crossbrace)

MINIMUM BRACING REQUIREMENTS DIAGRAM

1	X							
2	X	X						
3	X		X					
4	X			X				
5	X				X			
6	X			X		X		
7	X			X			X	
8	X				X			X
9	X				X			X

X = DENOTES BRACED SECTION



REGULAR DUTY



HEAVY DUTY

Product Options and Numbers

Example Part #: **SSX 4 48 R GLV**

S-Series Crossbrace: **SSX**

Section Width: 3', 4'

Section Height: 36", **48"**, 60", 72", 84", 96", 108", 120", 144"

Bracing Type: R, H

Standard Finish: **GLV**

Suffix Key	
R	- Regular Duty Crossbrace
H	- Heavy Duty Crossbrace
GLV	- Galvanized